



Position clip washers inside the leg struts, facing outward as shown. One per leg. The 90 degree tabs fit on top of the ring above and between the bottom of the ring and welded bar below. Acorn nut facing outwards with grip washer positioned between acorn nut and clip washer.

Slot in clip washer allows for vertical adjustment to fit, as needed. Tighten acorn nut and grip washer securely to prevent movement of the stand legs.